

# WATER BUBBLER

## CLEANING INSTRUCTIONS

To maintain the performance, hygiene, and warranty validity of your water bubbler, please adhere to the following guidelines.

### General Safety Guidelines

- Do NOT immerse the water bubbler in water for any reason.
- Do NOT use pressure washers or power cleaning devices to clean, service, or maintain the unit.
- Always follow the manufacturer's instructions as outlined in the user manual.

### External Cleaning

- Disconnect the unit from power before cleaning.
- Wipe the exterior surfaces with a soft cloth and mild dishwashing liquid.
- Do NOT use bleach, abrasive cleaners, or scouring pads.
- Use a vacuum cleaner to remove dust and lint from external vents and air intake areas.
- Frequently clean high-touch areas such as faucets and buttons using food-safe disinfectant wipes.

# 1

### Clean faucet area

- Wipe down the faucet and surrounding areas using a mild food-grade disinfectant.

# 2

### Disassemble for thorough cleaning

- Follow the disassembly steps in the unit's user manual.
- Carefully remove all washable components.

# 3

### Wash and sanitise

- Clean components with a suitable, non-abrasive cleaning solution.
- Sanitize with a solution of 2 mL bleach per 1 litre of water.
- Rinse thoroughly with potable water to remove all traces of bleach.

# 4

### Dry and reassemble

- Ensure all parts are fully dried before reassembling the unit.
- Reconnect the unit to the power supply only after cleaning is complete.

**Note:** Only trained personnel should perform disassembly and internal cleaning. If in doubt, please contact your service provider or distributor.